



# “What each Button does”

## Pat’s “10 LED’s / 12 Tunes IR Light Tower + Auto”

Pat McMahon Version 3 11/3/2024

Note– It uses 29 of 40 possible buttons.

Note– The **MUTE (HAIER)** button on the top right, makes it continuously run through all the functions automatically. It won’t stop until the power is turned off.

Australian National Anthem

Adam’s family

Mission Impossible

Inspector Gadget

Sesame Street

Beat It

Infra= 77 Green

Infra= 76 Red

Infra= 60 Sound

Infra= 54 Sleep

Infra= 26 >

Infra= 27 <<

Infra= 21 Power

Infra= 20 Mute Manual (Automatic)

Infra= 78 Yellow Funky Town

Infra= 79 Blue Happy Days

Infra= 24 Wide Jurassic Park

Infra= 61 PC/ You were made for Loving Me

Infra= 25 II Star Wars -Imperial March

Infra= 28 >> Indiana Jones

No Infra

Infra= 118 Pic All LED’s On

Infra= 101 AIWA All LED’s Off

Infra= 51 Thomson Cave Out x6

Infra= 117 Skyworth Down Wave x4

Infra= 118 Sys

Infra= 37 TV/AV

Infra= 16 CH +

Infra= 58 Display

Infra= 17 CH -

Infra= 1 SONY 2 LED 2

Infra= 2 Panasonic 3 LED 3

Infra= 4 Hitachi 5 LED 5

Infra= 5 Toshiba 6 LED 6

Infra= 7 LG 8 LED 8

Infra= 8 Samsung 9 LED 9

Infra= 9 Funai 0 LED 10

Infra= 59 Changhong

Infra= 96 Mix

Up Wave x4 Infra= 116 Chinese TV

Cave In x6 Infra= 52 JVC

Infra= 23 Menu

Infra= 18 Vol +

Infra= 19 Vol -

LED 1 Infra= 0 Sharp 1

LED 4 Infra= 3 Sanyo 4

LED 7 Infra= 6 Phillips 7

Infra= 29 Erisson-/--

Pat’s Infra Debug Program


```
main:
irin 3, b1
debug pause
500
goto main
```

Infrared Remote –M  
To set to SONY Protocol

Power + 2 (SONY)



IR Remote  
LR-LCD-707E



Name-